



# USER GUIDE & INSTALLATION INSTRUCTIONS

1092 Continental Induction G5

#### SLOW BAKED LEG OF LAMB



#### **INGREDIENTS**

- 2-3 large sprigs of rosemary
- 4 large garlic cloves cut in half lengthways
- 1.8 kg leg of lamb
- 8 good quality anchovy fillets, halved
- 100 ml olive oil
- 250 ml dry red wine
- Maldon salt and freshly ground black pepper

#### **METHOD**

- Preheat the oven to 220 °C (for a conventional oven), 200 °C (for a fan oven) or gas mark 7.
- 2. Pull the small sprigs off the rosemary branches and set aside with the garlic.
- 2. Using the tip of a paring knife, make up to 20 well-spaced cuts into the flesh of the lamb, about 2.5 cm inch deep. Divide the rosemary sprigs, garlic and anchovies and push down into the cuts. Place the leg on a large roasting tin and pour over the oil, massaging it all over the joint. Season well with salt and pepper and pour the wine and 250 ml water into the tin.
- 3. Put into the oven and sear for 15 minutes, then turn the temperature right down to 130 °C (conventional oven), 110 °C (fan oven) or gas mark 1 and roast for 4–5 hours, basting every 30 minutes or so. Basting frequently helps to keep the meat moist and encourages the build up of a good glaze on the outside. Add more liquid (wine or water) if the tin looks dry there should always be liquid in the tin throughout this cooking process.
- 4. The meat is ready when it starts to fall off the bone, at which point it should have a core temperature of 90 °C. Remove from the oven, transfer to a warmed carving dish, cover loosely with foil and leave to rest in a warm place for 30–45 minutes before carving.
- 5. Pour the juices from the tin into a tall hi-ball glass and allow to settle. Spoon the fat from the top of the glass. There should be enough sticky, reduced juices for an intense gravy hit if not, pour the juices you have back into the roasting tin and put it over the heat, pour in a splash of water or wine and deglaze the tin scraping up all the sticky bits from the base. Boil fast until syrupy, taste and correct the seasoning.

# RASPBERRY SOUFFLÉ...



#### **INGREDIENTS**

- 400 g raspberries
- 1 tbsp lemon juice
- 100 g caster sugar
- 2 tsp crème de framboise
- 1 tsp cornflour
- 180 q eqq whites (about 6)
- Pinch of cream of tartar or a squeeze of lemon juice
- Icing sugar for dusting

#### **METHOD**

- For the soufflé, press the raspberries through a fine sieve to produce 180 g of purée. Put this into a heavybottomed pan, add the lemon juice and reduce down to a thick jam, stirring from time to time and being careful not to let it catch and burn.
- 2. Put 45 g of the sugar in a separate pan. Melt it and then boil until it becomes a thick syrup (121 °C on a sugar thermometer). To test without a thermometer, dip a teaspoon into the syrup and then dip quickly into cold water. You should be able to roll the cooling syrup into a ball between your fingers. Be careful as the syrup is extremely hot. When it has reached the right point, stir the hot syrup into the raspberry jam.
- Mix the framboise and cornflour together and stir into the jam over the heat. Turn the jam into a small bowl, sprinkle the surface with icing sugar and cover with cling film
- Preheat the oven (not grill) to 180 °C shelf level 2 (conventional oven), 160 °C (fan oven) or gas mark 4 centre shelf.
- 5. Whisk the egg whites with the cream of tartar until you can form soft peaks, then fold in the remaining caster sugar. Lightly fold the whites into the jam, leaving thin traces of white visible in the mixture.
- 6. Spoon into four large buttered and sugared ramekins, place these on a baking tray and bake for 10 minutes.
- 7. Dust with icing sugar.

# **Contents**

1.	Before You Start	1	6.	Troubleshooting	16
	Installation and Maintenance	1	7.	Installation	18
	Peculiar Smells	1		Dear Installer	18
	Ventilation	1			
	Personal Safety	1		Safety Requirements and Regulations	18
	Hob Care	3		Provision of Ventilation	18
	Cooker Care	3		Location of Cooker	18
_				Positioning the Cooker	19
2.	Cooker Overview	4		Moving the Cooker	19
	The Hob	4		Repositioning the Cooker Following	20
	The Ovens	8		Connection	
	Accessories	10		Levelling	20
3.	Cooking Tips	11		Electrical Connection	21
<b>J.</b>	<u> </u>			Final Checks	21
	Hints on Using Your Induction Cooker	11		Final Fitting	22
	General Oven Tips	11		Customer Care	22
4.	Cooking Table	12	8.	Circuit Diagrams	23
5.	Cleaning Your Cooker	13		Induction Hob Circuit Diagram	23
	Hob	13		Oven Circuit Diagram	24
	Control Panel and Doors	14	9.	Technical Data	25
	Ovens	14			
	Cleaning Table	15			



## 1. Before You Start...

Thank you for buying this cooker. It should give you many years of trouble-free cooking if installed and operated correctly. It is important that you read this section before you start, particularly if you have not used an induction cooker before.



This appliance is designed for domestic cooking only. Using it for any other purpose could invalidate any warranty or liability claim. In particular, the oven should NOT be used for heating the kitchen besides invalidating claims this wastes fuel and may overheat the control knobs.

#### Installation and Maintenance

All installations must be in accordance with the relevant instructions in this booklet, with the relevant national and local regulations, and with the local electricity supply companies' requirements.

Make sure that the cooker is correctly wired and switched on.

#### The hob control display will flash for about 2 seconds during first power setting - this is normal.

Only a qualified service engineer should service the cooker, and only approved spare parts should be used.

Always allow the cooker to cool and then switch it off at the mains before cleaning or carrying out any maintenance work, unless specified otherwise in this guide.

#### **Peculiar Smells**

When you first use your cooker it may give off an odour. This should stop after use.

Before using your cooker for the first time, make sure that all packing materials have been removed and then, to dispel manufacturing odours, turn all the ovens to 200 °C and run for at least an hour.

Make sure the room is well ventilated to the outside air (see 'Ventilation' below). People with respiratory or allergy problems should vacate the area for this brief period.

#### Ventilation



**A** CAUTION: The use of a cooking appliance results in the production of heat and moisture in the room in which it is installed. Therefore, make sure that the kitchen is well ventilated: keep natural ventilation holes open or install a powered cookerhood that vents outside. If you have several hotplates on, or use the cooker for a long time, open a window or turn on an extractor fan.

## **Personal Safety**

Important information for pacemaker and implanted insulin pump users: The functions of this hob comply with the applicable European standards on electromagnetic interference. If you are fitted with a pacemaker or implanted insulin pump and are concerned please consult your doctor for medical advice.



DO NOT modify this appliance.



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.



#### **WARNING!**

The appliance and its accessible parts become hot during use and will retain heat even after you have stopped cooking. Care should be taken to avoid touching heating elements. Children less than 8 years of age shall be kept away unless continuously supervised.



When the hob is in use keep magnetic items, such as credit and debit cards, floppy disk, calculators, etc. away.



A CAUTION: A long term cooking process has to be supervised from time to time. A short term cooking process has to be supervised continuously.



▲ Danger of fire: DO NOT store items on the cooking surfaces.



To avoid overheating, DO NOT install the cooker behind a decorative door.



Accessible parts will become hot during use and will retain heat even after you have stopped cooking. Keep babies and children away from the cooker and never wear loose-fitting or hanging clothes when using the appliance.



**A** DO NOT use a steam cleaner on your cooker.

Always be certain that the controls are in the OFF position when the oven is not in use, and before attempting to clean the cooker.





Take care when touching the marked cooking areas



When the oven is on, DO NOT leave the oven door open for longer than necessary, otherwise the control knobs may become very hot.

Always keep combustible materials, e.g. curtains, and flammable liquids a safe distance away from your cooker.





# DO NOT spray aerosols in the vicinity of the cooker while it is on.

Cooking high moisture content foods can create a 'steam burst' when an oven door is opened (Fig.1-1). When opening an oven stand well back and allow any steam to disperse.

Use dry oven gloves when applicable – using damp gloves might result in steam burns when you touch a hot surface. Do not use a towel or other bulky cloth in place of a glove – it might catch fire if brought into contact with a hot surface.

NEVER operate the cooker with wet hands.

DO NOT use aluminium foil to cover shelves, linings, the oven roof or oven base.

NEVER heat unopened food containers. Pressure build up may make the containers burst and cause injury.

DO NOT use unstable saucepans. Always make sure that you position the handles away from the edge of the hotplate.

Never leave the hotplate unattended at high heat settings. Pans boiling over can cause smoking, and greasy spills may catch on fire. Use a deep fat thermometer whenever possible to prevent fat overheating beyond the smoking point.

**★** WARNING!

Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.

NEVER leave a chip pan unattended. Always heat fat slowly, and watch as it heats. Deep fry pans should be only one third full of fat. Filling the pan too full of fat can cause spill over when food is added. If you use a combination of oils or fats in frying, stir them together before heating, or as the fats melt.

Foods for frying should be as dry as possible. Frost on frozen foods or moisture on fresh foods can cause hot fat to bubble up and over the sides of the pan. Carefully watch for spills or overheating of foods when frying at high or medium high temperatures. Never try to move a pan of hot fat, especially a deep fat fryer. Wait until the fat is cool.

Do not use the top of the flue (the slot along the back of the cooker) for warming plates, dishes, drying tea towels or softening butter.

DO NOT use water on grease fires and never pick up a flaming pan. Turn off the controls and then smother a flaming pan on a surface unit by covering the pan completely with a well fitting lid or baking tray. If available, use a multi-purpose dry chemical

Take care that no water seeps into the appliance.

or foam-type fire extinguisher.

This appliance is heavy so take care when moving it.

NEVER allow anyone to climb or stand on the hob.

## **Hob Care**

**NEVER cook directly on the hob surface (Fig.1-2).** 

**A** DO NOT use the hob surface as a cutting board.

DO NOT leave utensils, foodstuffs or combustible items on the hob when it is not is use (e.g. tea towels, frying pans containing oil).

A

DO NOT place plastic or aluminium foil, or plastic containers, on the hob.



DO NOT leave the hob zones switched on unless being used for cooking.

DO NOT stand or rest heavy objects on the hob. Although the ceramic surface is very strong, a sharp blow or sharp falling object (e.g. a salt cellar) might cause the surface to crack or break (Fig.1-3).



Should a crack appear in the surface, disconnect the appliance immediately from the supply and arrange for its repair.

Always LIFT pans off the hob. Sliding pans may cause marks and scratches (**Fig.1-4**). Always turn the control to the OFF position before removing a pan.





Take care when placing hot lids onto the hob surface. Lids that have been covering boiling or steaming foods can 'stick' to the ceramic glass. Should this occur, DO NOT attempt to lift the lid off the hotplate: this may damage the hob surface.


DO NOT place anything between the base of the pan and the hob surface (e.g. asbestos mats, aluminium foil, wok stand).

#### **Cooker Care**


As steam can condense to water droplets on the cool outer trim of the oven, it may be necessary during cooking to wipe away any moisture with a soft cloth. This will also help to prevent soiling and discolouration of the oven exterior by cooking vapours (Fig.1-5).









## 2. Cooker Overview







Your induction cooker (Fig.2-1) has the following features:

- **A.** 5 induction cooking zones
- **B.** Control panel
- **C.** Multi-function oven
- **D.** Fan oven
- E. Storage drawer

#### The Hob

Use only pans that are suitable for induction hobs. We recommend stainless steel, enamelled steel pans or cast iron pans with enamelled bases. Note that some stainless steel pans are not suitable for use with an induction hob so please check carefully before purchasing any cookware.

Pans made of copper, aluminium or ceramic are not suitable for use on an induction hob. The kind of pan you use and the quantity of food affects the setting required. Higher settings are required for larger quantities of food.

Pots and pans should have thick, smooth, flat bottoms (Fig.2-2). This allows the maximum heat transfer from the hob to the pan, making cooking quick and energy efficient. Never use a round-bottomed wok, even with a stand.

The very best pans have bases that are very slightly curved up when cold (**Fig.2-3**). If you hold a ruler across the bottom you will see a small gap in the middle. When they heat up the metal expands and lies flat on the cooking surface.

Make sure that the base of the pan is clean and dry to prevent any residue burning onto the hob panel. This also helps prevent scratches and deposits.



Take care when placing hot lids onto the hob surface. Lids that have been covering boiling or steaming foods can 'stick' to the ceramic glass. Should this occur, DO NOT attempt to lift the lid off the hotplate: this may damage the hob surface. Instead, carefully slide the lid to the edge of the hob surface and remove.

Always use pans that are the same size as (or slightly larger than) the areas marked on the hob. Using a lid will help the contents boil more quickly.



Always take care before touching the surface, even when the hob is turned off. It may be hotter than you think!

The induction hob comprises of five cooking zones containing induction elements with different ratings and diameters (**Fig.2-4**) each with a pan detector and residual heat indicator, and a hob control display.

The hob control display (**Fig.2-5**) informs you of the following induction hob functions:

Pan Detector

H Residual Heat Indicator

**R** Automatic Heat-up

Child Lock

L1/L2 Low Temperature Setting

P Power Boost Setting


#### Pan Detector, $\underline{\dot{}}$


**IMPORTANT:** After use, switch off the hob element by its control and DO NOT RELY on the pan detector.

If a cooking area is switched on and there is no pan in place or if the pan is too small for the cooking area, then no heat will be generated. The symbol [½] will appear on the hob control display; this is the "pan-missing symbol". Place a pan of the correct size on the cooking area and the [½] symbol will disappear and cooking can begin. After 10 minutes without detecting a pan the cooking zone will switch off automatically.

**Table 2-1** shows the minimum pan sizes recommended for each cooking zone.

**Note:** Using pans with a base diameter smaller than those recommended will result in a power reduction.







Cooking Zone	Minimum Pan Diameter (Pan Base) mm
Front left	120
Rear left	140
Centre	160
Rear right	140
Front right	140

Table 2-1

Power Level	Automatic Heat-up Time at 100% (min:sec)
1	0:48
2	2:24
3	3:50
4	5:12
5	6:48
6	2:00
7	2:48
8	3:36
9	

Table 2-2





#### Residual Heat Indicator, H

After use, a cooking zone will remain hot for a while as heat dissipates. When a cooking zone is switched off the residual heat indicator symbol [H], will appear in the display. This shows that the cooking zone temperature is above  $60\,^{\circ}\text{C}$  and may still cause burns. Once the temperature has dropped to below  $60\,^{\circ}\text{C}$  the [H] will go out.

#### Automatic Heat-up, 8

This function is available on all of the cooking zones. It allows rapid heating up of the element to bring the selected cooking zone up to temperature. Once the zone is at the required cooking temperature the power level will reduce automatically to the preset level.

The function is selected by turning the control knob to the 'A' position. Turn the control knob momentarily counter-clockwise from the zero position until the symbol [#] is shown on the hob control display.

Once the [8] is displayed, turn the control knob to the level of your choice (1 to 9). The pan will heat up at 100% power for a specified time before the power is reduced to the level selected.

When the Automatic Heat-up function is activated, the hob control display will flash alternately between the [8] setting and the chosen power level.

Once the Automatic Heat-up time has ended the hob display will stop flashing and will show the chosen power level.

The Automatic Heat-up function can be stopped by either turning the control knob back to the "0" power setting or turning the control knob to the "9" power setting.

For your guidance **Table 2-2** shows the time available at 100% power depending on the power level selected in the Automatic Heat-up mode.

#### Child Lock, **=** □

**IMPORTANT:** The child lock can only be activated when all the cooking zones are switched off.

To prevent the unwanted use by children, the hob can be locked.

To lock the hob, simultaneously turn the two left-hand hob controls counter-clockwise (Fig.2-6) and hold until the symbol appears in the centre of the hob control display (Fig.2-7).

**Note:** [8] will flash when locking the hob – this is normal.

Locking the hob will NOT affect the oven; it can still be used.

To unlock the hob, simultaneously turn the two left-hand controls counter-clockwise and hold until the symbol disappears from the centre of the hob control display.

#### Low Temperature Setting, L1/L2

Each cooking area is equipped with 2 low temperature settings:

- L1 will maintain a temperature of about 40 °C ideal for gently melting butter or chocolate.
- *L*<sup>2</sup> will maintain a temperature of about 90 °C − ideal for simmering (bring the pan to the boil and then select L2 to keep soups, sauces, stews, etc at an optimal simmer).

The maximum time this setting can be used is 2 hours, after which the hob will switch off automatically. If required, you can immediately restart the Low Temperature function by reactivating L1 or L2. To increase the heat, just turn the control knob to the required level.

The maximum times for all other power levels are shown in **Table 2-3**.

#### Power Boost Setting, P

All of the induction cooking zones have Power Boost available, activated by turning the control knob clockwise until [P] is shown on the hob control display.

Power Boost allows additional power to be made available for each of the cooking zones. This is useful to bring a large pan of water to the boil quickly.

The Power Boost function operates for a maximum of 10 minutes on each zone, after which the power is automatically reduced to setting 9.

When using the Power Boost function, the cooking zones are linked.

Fig.2-8 shows the hob layout. Zones A and B are linked together as are zones D and E.

This means that when using zone A on Power Boost and then switching zone B to Power Boost, then the power to zone A will reduce slightly. The last zone switched to Power Boost always takes priority. Zones D and E work in the same way.



#### ▲ This is a built-in safety device.

Deactivate the Power Boost function by turning the control knob to a lower setting.

#### **Overheat Function**


This function identifies when the temperature of the pan rises rapidly and works to maintain a safe level of pan temperature. It should not interfere with normal cooking.



Please remember not to leave the hob unattended. Care should be taken to not allow your cookware to boil drv.

Power Level	Maximum Operating Time
L1 and L2	2 hours
1	6 hours
2	6 hours
3	5 hours
4	5 hours
5	4 hours
6	1.5 hours
7	1.5 hours
8	1.5 hours
9	1.5 hours
Power Boost	10 minutes

Table 2-3



#### The Ovens

References to 'left-hand' and 'right-hand' ovens apply as viewed from the front of the appliance.

The left-hand oven is a multi-function oven, while the righthand oven is a fan oven.

#### The Multi-function Oven

Multi-function ovens have an oven fan and oven fan element, as well as two extra heating elements. One element is in the top of the oven and the second is under the oven base. Take care to avoid touching the top element and element deflector when placing or removing items from the oven.

The multi-function oven has 3 main cooking functions: fan, fan assisted and conventional cooking. These functions should be used to complete most of your cooking.

The **browning element** and **base heat** can be used in the latter part of the cooking process to fine tune the results to your particular requirements.

Use fanned grilling for all your grilling needs and defrost to safely thaw small items of frozen food.

**Table 2-4** gives a summary of the multi-function modes.

The multi-function oven has many varied uses. We suggest you keep a careful eye on your cooking until you are familiar with each function. Remember, not all functions will be suitable for all food types.

#### **Multi-function Oven Functions**

#### Fan Oven



This function operates the fan and the heating element around it. An even heat is produced throughout the oven, allowing you to cook large amounts quickly.

Fan oven cooking is particularly suitable for baking on several shelves at one time and is a good 'all-round' function. It may be necessary to reduce the temperature by approximately 10 °C for recipes previously cooked in a conventional oven.

If you wish to preheat the oven, wait until the indicator light has gone out before inserting the food.

#### **Fanned Grilling**



This function operates the fan while the top element is on. It produces a more even, less fierce heat than a conventional grill. For best results, place the food to

be grilled, on a trivet over a roasting tin, which should be smaller than a conventional grill pan. This allows greater air circulation. Thick pieces of meat or fish are ideal for grilling in this way, as the circulated air reduces the fierceness of the heat from the grill.

The oven door should be kept closed while grilling is in progress, so saving energy. You will also find that the food needs to be watched and turned less than for normal grilling. Preheat this function before cooking.

For best results we recommend that the grill pan is not located on the top shelf.

#### **Fan Assisted Oven**



This function operates the fan, circulating air heated by the elements at the top and the base of the oven. The combination of fan and conventional cooking

(top and base heat) makes this function ideal for cooking large items that need thorough cooking, such as a large meat roast.

It is also possible to bake on two shelves at one time, although they will need to be swapped over during the cooking time, as the heat at the top of the oven is greater than at the base, when using this function.

This is a fast intensive form of cooking; keep an eye on the food cooking until you have become accustomed to this function.

#### **Conventional Oven (Top and Base Heat)**



This function combines the heat from the top and base elements. It is particularly suitable for roasting and baking pastry, cakes and biscuits.

Food cooked on the top shelf will brown and crisp faster than on the lower shelf, because the heat is greater at the top of the oven than at the base, as in 'Fan Assisted Oven' function. Similar items being cooked will need to be swapped around for even cooking. This means that foods requiring different temperatures can be cooked together, using the cooler zone in the lower half of the oven and hotter area to the top.

The exposed top element may cook some foods too quickly, so we recommend that the food be positioned in the lower half of the oven to cook. The oven temperature may also need to be lowered.

Similar items being cooked will need to be swapped around for even cooking.

#### **Browning Element**

This function uses the element in the top of the oven only. It is a useful function for the browning or finishing of pasta dishes, vegetables in sauce, shepherds pie and lasagne, the item to be browned being

already hot before switching to the top element.

#### **Base Heat**



This function uses the base element only. It will crisp up your pizza or quiche base or finish off cooking the base of a pastry case on a lower shelf. It is also a

gentle heat, good for slow cooking of casseroles in the middle of the oven or for plate warming.

The Browning and Base Heat functions are useful additions to your oven, giving you flexibility to finish off items to perfection.

#### Defrost



This function operates the fan to circulate cold air only. Make sure the temperature control is at 0°C and that no heat is applied. This enables small items such

as desserts, cream cakes and pieces of meat, fish and poultry to be defrosted.

Defrosting in this way speeds up the process and protects the food from flies. Pieces of meat, fish and poultry should be placed on a shelf, over a tray to catch any drips. Be sure to wash the shelf and tray after defrosting.

Defrost with the oven door closed.

Large items, such as whole chickens and joints should not be defrosted in this way. We recommend this be carried out in a refrigerator.

Defrosting should not be carried out in a warm oven or when an adjoining oven is in use or still warm. Make sure that dairy foods, meat and poultry are completely defrosted before cooking.

#### **The Fan Oven**

Fan ovens circulate hot air continuously, which means faster, more even cooking. The recommended cooking temperatures for a fan oven are generally lower than those for a non-fan oven.

**Note:** Please remember that all cookers vary so temperatures in your new ovens may differ to those in your previous cooker.

#### **Operating the Ovens**

#### Fan Oven

Turn the oven knob to the desired temperature (Fig.2-9).

The oven indicator light will glow until the oven has reached the temperature selected. It will then cycle on and off during cooking.

#### **Multi-function Oven**


The multi-function oven has two controls: a function selector and a temperature setting knob (**Fig.2-10**).


Turn the function selector control to a cooking function. Turn the oven temperature knob to the temperature required.


The oven heating light will glow until the oven has reached the temperature you selected. It will then cycle on and off during cooking (Fig.2-11).


Function	Use
Defrost	To thaw small items in the oven without heat
Fan oven	A full cooking function, even heat throughout, great for baking
Fanned grilling	Grilling meat and fish with the door closed
Fan assisted	A full cooking function good for roasting and baking
Conventional oven	A full cooking function for roasting and baking in the lower half of the oven
Browning element	To brown and crisp cheese topped dishes
Base heat	To crisp up the bases of quiche, pizza or pastry


Table 2-4














#### **Accessories**

#### **Oven Shelves**

In addition to the flat shelves your cooker is supplied with drop shelves (**Fig.2-12**). The drop shelf increases the possibilities for oven shelf spacing.

The oven shelves can be easily removed and refitted.

Pull the shelf forward until the back of the shelf is stopped by the shelf stop bumps in the oven sides (Fig.2-13).

Lift up the front of the shelf so the back of the shelf will pass under the shelf stop and then pull the shelf forward (Fig.2-14).

To refit the shelf, line up the shelf with a groove in the oven side and push the shelf back until the ends hit the shelf stop. Lift up the front so the shelf ends clear the shelf stops, and then lower the front so that the shelf is level and push it fully back (Fig.2-15).

# 3. Cooking Tips

## **Hints on Using Your Induction Cooker**

If you have not used an induction cooker before please be aware of the following:

- Make sure that the pans you have or buy are suitable for use on the induction hob. Stainless steel, enamelled steel or cast iron is ideal. Double check before you buy pans – they must have bases that would attract a magnet.
- Allow time to get used to induction cooking; it is fast and powerful as well as being gentle. When simmering, you may notice that liquids appear to stop bubbling and then start again almost immediately. This is perfectly normal.
- You may notice a faint vibrating sound coming from the pans when using the induction hob. Again, this is perfectly normal and will depend upon the type and style of pans you are using.
- The induction heating elements will phase on and off when cooking. Although an active cooking zone may appear to switch on and off, a constant heat is still being supplied to the base of the pan – this is completely normal.

## **General Oven Tips**

The wire shelves should always be pushed firmly to the back of the oven.

Baking trays with food cooking on them should be placed level with the front edge of the oven's wire shelves. Other containers should be placed centrally. Keep all trays and containers away from the back of the oven, as overbrowning of the food may occur.

For even browning, the maximum recommended size of a baking tray is  $340 \, \text{mm} \, (13 \, \frac{1}{2})$  by  $340 \, \text{mm} \, (13 \, \frac{1}{2})$ .

When the oven is on, do not leave the door open for longer than necessary, otherwise the knobs may get very hot.


- Always leave a "finger's width" between dishes on the same shelf. This allows the heat to circulate freely around them.
- To reduce fat splashing when you add vegetables to hot fat around a roast, dry them thoroughly or brush lightly with cooking oil.
- Where dishes may boil and spill over during cooking, place them on a baking tray.
- The 'Cook & Clean' oven liners (see 'Cleaning Your Cooker') work better when fat splashes are avoided.
   Cover meat when cooking.
- If you want to brown the base of a pastry dish, preheat the baking tray for 15 minutes before placing the dish in the centre of the tray.

# 4. Cooking Table

The oven control settings and cooking times given in the table below are intended to be used **AS A GUIDE ONLY**. Individual tastes may require the temperature to be altered to provide a preferred result.

Food is cooked at lower temperature in a fan oven than in a conventional oven. When using recipes, reduce the fan oven temperature by  $10\,^{\circ}$ C and the cooking time by 5-10 minutes. The temperature in the fan oven does not vary with height in the oven so you can use any shelf.

Conventional Oven Fan Oven



T - Top:	C-	Centre;	R-	Rase
ι - ιυρ,	C -	Ceritie,	υ-	Duse

Lamb   160 (C)   190   20-25 minutes per 500g +20-25 minutes   200 (C) for fan own) and the 201 (C) for fan own and the 201 (C) for fan		Temperature °C	Temperature	9	·	
Rear   Incorporation   Rear   Incorporation	Food	(Shelf Position)	°C	Approximate Cooking Time		
Lamb	Meat					
Lamb	Beef (no bone)	160 (C)	150	30-35 minutes per 500g +30-35 minutes.		
Lamb		200 (C)	190	20-25 minutes per 500g +20-25 minutes.		
Pork	Lamb	160 (C)	150	30-35 minutes per 500g +30-35 minutes.	cooking time adjusted accordingly.	
Pork   150   C)   150   35-40 minutes per 500g +25-30 minutes.		200 (C)	190	25-30 minutes per 500g +25-30 minutes.		
Poultry         Poultry         minutes per 500g +25-30 minutes.         minutes per and/or.         minutes per 400g +25-30 minutes.         minutes per 300g +25-30 minutes.         minutes per 500g +20-25 minutes.         for stuffed poultry, you could cook at 200°C (190°C) for 20 minutes.           Chicken         160 (C)         150         20°minutes per 500g +15-20 minutes.         a20°C (190°C) for 20 minutes at 20°C (190°C) for 20 minutes at 20°C (190°C) for 20 minutes.         a20°C (190°C) for 20 minutes per 500g +15 minutes.         bon to forget to include the weight of the stuffing of the stuffi	Pork	160 (C)	150	35-40 minutes per 500g +35-40 minutes.	approximately 10 minutes per 500g, — or cook at 200°C (190°C) for 20	
Chicken		200 (C)	190	25-30 minutes per 500g +25-30 minutes.	minutes then 160°C (150°C) for the	
Turkey         200 (C)         190         15-20 minutes per 500g +15-20 minutes.         at 200° (190° C) for 20 minutes hen 160° (150° C) for 20 minutes hen 160° (150° C) for 20 minutes hen 160° (150° C) for remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 160° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not longet to include the weight of the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long the 150° C (150° C) or remainder to not long	Poultry				remainder.	
Turkey	Chicken	160 (C)	150	20-25 minutes per 500g +20-25 minutes.		
Turkey		200 (C)	190	15-20 minutes per 500g +15-20 minutes.		
Part	Turkey	160 (C)	150	20 minutes per 500g +20 minutes.		
Policy   190   20 minutes per 500g.   pack. Throroughly that froze on the pack for poultry, follow instructions on the pack for poultry before cooking.		200 (C)	190	15 minutes per 500g +15 minutes.	of the stuffing.	
Casserole         140-150 (C)         190         20 minutes per 500g.         pack Throughly thaw frozen poultry before cooking.           Vorkshire Pudding         220 (C)         210         Large tins 30-35 minutes; individual 10-20 minutes.         moultry before cooking.           Cake         Very rich fruit - Christma, wedding, etc.         140 (C/B)         130         45-50 minutes per 500g of mixture.         Using the conventional oven: when two tier cooking leave at least one runner space between shelves. Position the baking law with the Fruit 230 mm tin         150 (C/B)         140         2-2½ hours.         Using the conventional oven: when two tier cooking leave at least one runner space between shelves. Position the baking law with the fruit gray with the Fruit 230 mm tin         150 (C/B)         140         2-2½ hours.         Position the baking law with the fruit of the oven shelf.           Fruit 230 mm tin         150 (C/B)         140         Up to 3½ hours.         fruit edge along the front of the oven shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.         The stance oven shelf.           Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.         Up to three liers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being sare to leave at least one runner space between each shelf being sare to leave at least one runner space between each shelf being sare to leave at least one runner space between each	Duck	160 (C)	150	25-30 minutes per 500g.		
Caserole         140-150 (C)         130-140         2-4 hours according to recipe.         Poullry before cooking.           Yorkshire Pudding         220 (C)         210         Large tins 30-35 minutes; individual 10-20 minutes.           Cake           Very rich fruit - Christmas, wedding, etc.         140 (C/B)         130         45-50 minutes per 500g of mixture.         Using the conventional oven: whe wedding, etc.         two fier cooking leave at least one runner space between shelves. Position the baking tray with the fruit 230 mm tin         150 (C/B)         140         2-2½ hours.         Position the baking tray with the front of the own shelf.           Fruit 180 mm tin         150 (C/B)         150         80-90 minutes.         oven shelf.         oven shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.         oven shelf.         oven shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.         oven shelf.         oven shelf.           Yictoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.         Up to three liers can be cooked in a fan oven at the same lime but make successful starts.         Up to three liers can be cooked in a fan oven at the same lime but make successful starts.         Up to three liers can be cooked on.         space between each shelf being cooked on.           Fruit pies         200 (C/B)		200 (C)	190	20 minutes per 500g.		
Cake           Very rich fruit - Christmas, wedding, etc.         140 (C/B)         130         45-50 minutes per 500g of mixture.         Using the conventional oven: when two liter cooking leave at least one runner space between shelves. Fruit 180 mm tin         150 (C/B)         140         2-2½ hours.         Lunner space between shelves. Position the baking tray with the front edge along the front of the own shelf.           Fruit 230 mm tin         150 (C/B)         140         Up to 3½ hours.         front edge along the front of the own shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.         oven shelf.           Scones         220 (C/B)         210         10-15 minutes.         oven shelf.           Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.           Pusserts         Shortcrust tarts         200 (C/B)         190         20-30 minutes on a preheated tray.         space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         35-45 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         10-20 minutes a	Casserole	140-150 (C)	130-140	2-4 hours according to recipe.		
Very rich fruit - Christmas, wedding, etc.         140 (C/B)         130         45-50 minutes per 500g of mixture.         Using the conventional oven: when two lier cooking leave at least one runner space between shelves. Position the baking tray with the front edge along the front of the Madeira 180 mm         150 (C/B)         140         2-2½ hours.         Position the baking tray with the front edge along the front of the owner shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.         oven shelf.           Queen cakes         190 (C/B)         210         10-15 minutes.           Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.           210 mm tin         180 (C/B)         170         20-30 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.           Pesserts         Shortcrust tarts         200 (C/B)         190         20-30 minutes on a preheated tray.         sure to leave at least one runner space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         20-30 minutes on a preheated tray.         space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         20-30 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked	Yorkshire Pudding	220 (C)	210	Large tins 30-35 minutes; individual 10-2	0 minutes.	
wedding, etc.         Fruit 180 mm tin         150 (C/B)         140 2-2½ hours.         Itwo fier cooking leave at least one runner space between shelves. Position the baking tray with the front edge along the front of the degration of the degration of the power shelf.           Fruit 230 mm tin         150 (C/B)         150 80-90 minutes.         Position the baking tray with the front edge along the front of the oven shelf.           Queen cakes         190 (C/B)         180 15-25 minutes.         vern shelf.           Scones         220 (C/B)         210 10-15 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner space between each shelf being condended from the same time but make sure to leave at least one runner s	Cake					
wedding, etc.         two fier cooking leave at least one runner space between shelvies. Position the baking tray with the Fruit 230 mm tin         150 (C/B)         140 Up to 3½ hours.         two fier cooking leave at least one runner space between shelvies. Position the baking tray with the front edge along the front of the with the baking tray with the front edge along the front of the over shelf.           Queen cakes         190 (C/B)         180 15-25 minutes.         oven shelf.           Scones         220 (C/B)         210 10-15 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space between each shelf being sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of the sure time but make sure to leave at least one runner space of	Very rich fruit - Christmas	, 140 (C/B)	130	45-50 minutes per 500g of mixture.	Using the conventional oven: when	
Fruit 230 mm tin	wedding, etc.				two tier cooking leave at least one	
Fruit 230 mm tin         150 (C/B)         140         Up to 3½ hours.         front edge along the front of the over shelf.           Madeira 180 mm         160 (C/B)         150         80-90 minutes.         over shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.           Scones         220 (C/B)         210         10-15 minutes.           Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.           210 mm tin         180 (C/B)         170         30-40 minutes.         Up to three tiers can be cooked in a fan over at the same time but make sure to leave at least one runner space between each shelf being runner space between each shelf being runner space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         20-30 minutes on a preheated tray.         space between each shelf being cooked on.           Tartlets         200 (C/B)         190         35-45 minutes.         cooked on.           Tartlets         200 (C/B)         190         10-20 minutes according to size.           Puff pastry         210 (C/B)         200         20-40 minutes according to size.           Weringues         100 (C/B)         90         2-3 hours.         Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm x 340 mm rhis ensures free heat ci	Fruit 180 mm tin	_150 (C/B)	140	2-21/2 hours.		
Madeira 180 mm         160 (C/B)         150         80-90 minutes.         oven shelf.           Queen cakes         190 (C/B)         180         15-25 minutes.           Scones         220 (C/B)         210         10-15 minutes.           Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.           210 mm tin         180 (C/B)         170         30-40 minutes.         Up to three tiers can be cooked in a lan oven at the same time but make same time but make same time but make same time but make same to leave at least one runner space between each shelf being cooked on.           Pesserts         200 (C/B)         190         20-30 minutes on a preheated tray.         space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         35-45 minutes.         cooked on.           Tartlets         200 (C/B)         190         10-20 minutes according to size.           Puff pastry         210 (C/B)         200         20-40 minutes according to size.           Meringues         100 (C/B)         90         2-3 hours.         Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm as 340 mm. This ensures free heat for interesting the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm as 340 mm. This ensures free heat for illing         if cooking a two tier load, the trays shoul	Fruit 230 mm tin	150 (C/B)	140	Up to 31/2 hours.	front edge along the front of the	
Scones   220 (C/B)   210   10-15 minutes.	Madeira 180 mm	160 (C/B)	150	80-90 minutes.		
Victoria sandwich         180 mm tin         180 (C/B)         170         20-30 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.           Desserts         200 (C/B)         190         20-30 minutes on a preheated tray.         Space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         35-45 minutes.         cooked on.           Tartlets         200 (C/B)         190         10-20 minutes according to size.         cooked on.           Puff pastry         210 (C/B)         200         20-40 minutes according to size.         Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm.           Baked egg custard         160 (C/B)         150         45-60 minutes.         Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm.           Milk pudding         180 (C/B)         130-140         2 to 3 hours.         circulation.           Bread         210 (C)         200         20-30 minutes.         if cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.           Fish         Fanned Grilling         190 (C/B)         190 (C/B)         15-20 minutes per 500g.	Queen cakes	190 (C/B)	180	15-25 minutes.		
180 mm tin         180 (C/B)         170         20-30 minutes.           210 mm tin         180 (C/B)         170         30-40 minutes.         Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.           Desserts           Shortcrust tarts         200 (C/B)         190         20-30 minutes on a preheated tray.         space between each shelf being cooked on.           Fruit pies         200 (C/B)         190         35-45 minutes.         cooked on.           Tartlets         200 (C/B)         190         10-20 minutes according to size.           Puff pastry         210 (C/B)         200         20-40 minutes according to size.           Meringues         100 (C/B)         90         2-3 hours.         Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm. As a function of the maximum size of baking tray recommended is 340 mm. This ensures free heat circulation.           Bread         210 (C/B)         130-140         2 to 3 hours.         If cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.           Fish         Fanned Grilling         190 (C/B)         15-20 minutes.         cooking time.           Whole         190 (C/B)         190 (C/B)         15-20 minutes per 500g.  <	Scones	220 (C/B)	210	10-15 minutes.		
Desserts  Shortcrust tarts Shortcrust tarts Puff pastry Meringues Baked egg custard Baked sponge pudding Milk pudding Milk pudding Milk pudding  Figh Figh Fanned Grilling Fillet Whole  190 (C/B) 190 (C/B) 190 (C/B) 190 (C/B) 190 35-45 minutes.  200 (C/B) 190 10-20 minutes according to size.  Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.  190 (C/B) 190 10-20 minutes according to size.  Using the conventional oven: for even browning the maximum size of baking tray recommended is 340 mm. This ensures free heat circulation.  If cooking a two tier load, the trays should be interchanged approximately halfway though the Fillet 190 (C/B) 190 (C/B) 15-20 minutes.  Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.  100 (C/B) 190 (C/B) 190 (C/B) 190 (C/B) 15-20 minutes.  Up to three tiers can be cooked in a fan oven at the same time but make sure to leave at least one runner space between each shelf being cooked on.  100 (C/B) 190 (C/B)	Victoria sandwich					
Shortcrust tarts 200 (C/B) 190 20-30 minutes on a preheated tray. space between each shelf being cooked on.  Tartlets 200 (C/B) 190 10-20 minutes according to size.  Puff pastry 210 (C/B) 200 20-40 minutes according to size.  Meringues 100 (C/B) 90 2-3 hours.  Baked egg custard 160 (C/B) 150 45-60 minutes.  Milk pudding 140-150 (C/B) 130-140 2 to 3 hours.  Bread 210 (C/B) 190 (C/B) 15-20 minutes.  Fish Fanned Grilling  Fillet 190 (C/B) 190 (C/B) 15-20 minutes per 500g.	180 mm tin	180 (C/B)	170	20-30 minutes.		
Shortcrust tarts	210 mm tin	180 (C/B)	170	30-40 minutes.		
Shortcrust tarts Fruit pies  200 (C/B) 190 35-45 minutes.  Tartlets 200 (C/B) 190 10-20 minutes according to size.  Puff pastry Puff pastry 210 (C/B) 200 20-40 minutes according to size.  Puff pastry Puff pastr	Desserts					
Tartlets 200 (C/B) 190 10-20 minutes according to size.  Puff pastry 210 (C/B) 200 20-40 minutes according to size.  Meringues 100 (C/B) 90 2-3 hours.  Baked egg custard 160 (C/B) 150 45-60 minutes.  Baked sponge pudding 180 (C/B) 170 40-45 minutes.  Milk pudding 140-150 (C/B) 130-140 2 to 3 hours.  Bread 210 (C) 200 20-30 minutes.  Fish Fanned Grilling 4pproximately halfway though the Fillet 190 (C/B) 190 (C/B) 15-20 minutes per 500g.	Shortcrust tarts	200 (C/B)	190	20-30 minutes on a preheated tray.		
Puff pastry  Meringues Baked egg custard Baked sponge pudding Milk pudding  Bread  Ton (C/B)  Puff pastry  210 (C/B)  Puff pastry  100 (C/B)  90  2-3 hours.  45-60 minutes.  45-60 minutes.  40-45 minutes.  40-45 minutes.  40-45 minutes.  43-40 mm. This ensures free heat circulation.  140-150 (C/B)  130-140  2 to 3 hours.  150 cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.  Fillet  190 (C/B)  190 (C/B)  15-20 minutes per 500g.	Fruit pies	200 (C/B)	190	35-45 minutes.	cooked on.	
Puff pastry  Meringues Baked egg custard Baked sponge pudding Milk pudding  Bread  Ton (C/B)  Puff pastry  210 (C/B)  Puff pastry  100 (C/B)  90  2-3 hours.  45-60 minutes.  45-60 minutes.  40-45 minutes.  40-45 minutes.  40-45 minutes.  43-40 mm. This ensures free heat circulation.  140-150 (C/B)  130-140  2 to 3 hours.  150 cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.  Fillet  190 (C/B)  190 (C/B)  15-20 minutes per 500g.	Tartlets	200 (C/B)	190	10-20 minutes according to size.		
Baked egg custard  Baked sponge pudding  Milk pudding  Milk pudding  Bread  Tanned Grilling  Fillet  Mole  Mole  190 (C/B)  150  45-60 minutes.  45-60 minutes.  40-45 minutes	Puff pastry		200	20-40 minutes according to size.		
Baked sponge pudding Baked sponge pudding Milk pudding  Mi	Meringues	100 (C/B)	90	2-3 hours.	Using the conventional oven: for	
Baked sponge pudding Milk pudding         180 (C/B)         170         40-45 minutes.         x 340 mm. This ensures free heat circulation.           Bread         210 (C)         200         20-30 minutes.         If cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.           Fish Fillet         Fanned Grilling         190 (C/B)         15-20 minutes.           Whole         190 (C/B)         190 (C/B)         15-20 minutes per 500g.	Baked egg custard	160 (C/B)	150	45-60 minutes.	even browning the maximum size of	
Milk pudding         140-150 (C/B)         130-140         2 to 3 hours.         circulation.           Bread         210 (C)         200         20-30 minutes.         If cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.           Fish         Fanned Grilling         190 (C/B)         15-20 minutes.         cooking time.           Whole         190 (C/B)         190 (C/B)         15-20 minutes per 500g.			170	40-45 minutes.		
Bread210 (C)20020-30 minutes.If cooking a two tier load, the trays should be interchanged approximately halfway though the cooking time.FishFanned Grillingapproximately halfway though the cooking time.Fillet190 (C/B)190 (C/B)15-20 minutes per 500g.	Milk pudding		130-140	2 to 3 hours.	circulation.	
Fish         Fanned Grilling         Should be interchanged approximately halfway though the cooking time.           Fillet         190 (C/B)         190 (C/B)         15-20 minutes.         cooking time.           Whole         190 (C/B)         190 (C/B)         15-20 minutes per 500g.	· -			20-30 minutes.		
Fillet         190 (C/B)         190 (C/B)         15-20 minutes.         cooking time.           Whole         190 (C/B)         190 (C/B)         15-20 minutes per 500g.	Fish					
Whole 190 (C/B) 190 (C/B) 15-20 minutes per 500g.	Fillet		190 (C/B)	15-20 minutes.		
	Whole			15-20 minutes per 500g.		
	Steak			<u> </u>		

# 5. Cleaning Your Cooker

Isolate the electricity supply before carrying out any major cleaning. Allow the cooker to cool.




NEVER use paint solvents, washing soda, caustic cleaners, biological powders, bleach, chlorine based bleach cleaners, coarse abrasives or salt.



DO NOT mix different cleaning products – they may react together with hazardous results.

All parts of the cooker can be cleaned with hot soapy water – but take care that no surplus water seeps into the appliance.

Remember to switch the electricity supply back on before reusing the cooker.



#### Hob

#### **Daily Care**

First of all make sure that all heat indicator lights are off and that the cooking surface is cool. Apply a small dab of ceramic cleaning cream in the centre of each area to be cleaned. Dampen a clean paper towel and work the cream onto the cooking surface. As a final step, wipe the cooking surface with a clean, dry paper towel.

#### **Cleaning Spills**

For spills and boil-overs that occur while cooking, turn the unit off and wipe the area surrounding the hot zone with a clean paper towel. If a spill (other than a sugary substance) is on the hot zone, do not clean until the unit has completely cooled down, and then follow the instructions below ('Cleaning Burned-on Spills').

If you accidentally melt anything on the surface, or if you spill foods with a high sugar content (preserves, tomato sauce, fruit juice, etc.), remove the spill IMMEDIATELY with a razor scraper, while the unit is still hot.


# **IMPORTANT:** Use an oven glove to protect your hand from potential burns.


Scrape the major spill or melted material from the cooking zone and push into a cold area. Then, turn the unit 'OFF' and allow it to cool before cleaning further. After the cooking surface cools down and the heat indicator lights go off, follow the 'Daily Care' procedure outlined above.

#### **Cleaning Burned-on Spills**

Make sure that the heat indicator lights are off and that the hob is cool. Remove the excess burned-on substance with a single-edged razor scraper. Hold the scraper at an angle of about 30° to the surface and then scrape off the burned-on matter (Fig.5-1).

Once you have removed as much as possible with the scraper, follow the 'Daily Care' procedure outlined above.





#### **Control Panel and Doors**

Avoid using any abrasive cleaners including cream cleaners. For best results, use a liquid detergent. The same cleaner can also be used on the doors, or alternatively, using a soft cloth wrung out in clean hot soapy water – but take care that no surplus water seeps into the appliance. After cleaning, polish with a dry cloth.

#### **Glass Fronted Door Panels**

The oven door front panels can be taken off so that the glass panels can be cleaned. Move the cooker forward to gain access to the sides (see the 'Moving the Cooker' section under 'Installation'). Open the oven door slightly and remove the front panel fixing screws from the door sides, two each side (Fig.5-2).

Carefully lift off the outer door panel. The inside face of the glass panels can now be cleaned – take care not to disturb or wet the door insulation.

**Note:** If the door is triple glazed then the inner two panels are fixed together and should not be separated.

After cleaning, carefully refit the outer door panel and replace the side fixing screws.



DO NOT use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

#### **Ovens**

# Removing the Panels to Clean the Enamel Interior

If you wish to clean the enamel interior of the oven, you will need to remove the shelves before removing the panels. You do not have to remove the support brackets to remove the panels. Lift each panel upward and slide forward off the support brackets (**Fig.5-3**).

Once the panels have been removed, the oven enamel interior can be cleaned.



DO NOT use steel wool, oven cleaning pads, or any other materials that will scratch the surface.

Refit in the reverse order.

# **Cleaning Table**

Cleaners listed (**Table 5-1**) are available from supermarkets or electrical retailers as stated.

For enamelled surfaces use a cleaner that is approved for use on vitreous enamel.

Regular cleaning is recommended. For easier cleaning, wipe up any spillages immediately.

Hotplate			
Part	Finish	Recommended Cleaning Method	
Induction hob	Toughened glass	Hot soapy water; cream cleaner/scourer if necessary.	
Warming zone (some models only)	Toughened glass	Hot soapy water, cream cleaner/scourer if necessary.	
Outside of Cooker			
Part	Finish	Recommended Cleaning Method	
Door, door surround and storage	Enamel or paint	Hot soapy water, soft cloth. Any stubborn stains, remove gently with a liquid detergent.	
drawer exterior	Stainless steel	E-cloth (electrical retailers) or microfibre all-purpose cloth (supermarket).	
Sides and plinth	Painted surface	Hot soapy water, soft cloth.	
Splashback	Enamel or stainless steel	Hot soapy water, soft cloth. Cream cleaner, with care, if necessary.	
Control panel	Paint, enamel or stainless steel	Warm soapy water. Do not use abrasive cleaners on lettering.	
Control knobs/handles & trims	Plastic/chrome, copper or lacquered brass	Warm soapy water, soft cloth.	
	Brass	Brass polish.	
Oven door glass/glass lid (some models only)	Toughened glass Hot soapy water, cream cleaner/scourer if necessary.		
Oven			
Part	Finish	Recommended Cleaning Method	
Sides, floor & roof of oven	Enamel	Any proprietary oven cleaner that is suitable for enamel.  CAUTION: CORROSIVE/CAUSTIC OVEN CLEANERS: FOLLOW MANUFACTURER'S INSTRUCTIONS.  Do not allow contact with the oven elements.	
Oven shelves Chrome		An oven interior cleaner that is suitable for chrome. Soap filled pad. Dishwasher.	

Table 5-1

# 6. Troubleshooting



▲ Interference with and repairs to the hob MUST NOT be carried out by unqualified persons. Do not try to repair the hob as this may result in injury and damage to the hob. Please arrange for repair by a suitably competent person.

Note: The induction hob is able to self-diagnose a number of problems and can show this information to the user via the hob control display. Error codes may be displayed if your hob has developed a fault.

If your appliance reports an error or is not working, you may be able to correct the fault by consulting the following.

#### Error code E2 is displayed

The electronic unit is too hot. Please check the installation of the cooker, making sure that there is sufficient ventilation. In extreme cases, if a cooking utensil has been allowed to boil dry this error code may also be displayed. If in doubt please contact your installer or a qualified repair engineer.

#### No display operation

Over voltage or loss of supply voltage to the cooker. If in doubt please contact your installer or a qualified repair engineer.

#### Error code U400 is displayed

The cooker has been incorrectly connected. The control will switch off after approximately 1 second and the error code will be permanently displayed.

Consult your installer or a qualified repair engineer.

#### Error code Er followed by a number is displayed

The appliance has developed an internal technical fault that cannot be rectified by the user.

Consult your installer or a qualified repair engineer.

#### The fuse blows or the RCD trips regularly

Please contact your installer or a qualified repair engineer.

#### The hob will not switch on

Has the wiring system in the house blown a fuse or tripped an RCD?

Has the hob been correctly connected to the mains supply?

Has the child lock been activated? Please refer to the child lock section for details of this function.

#### The induction hob is noisy

When using the induction hob there may be some 'noise' emitted from the pan. This is normal and may be most noticeable when cooking on high power settings or if 5 pans are used simultaneously. The type of pan may also contribute to induction 'noise'.

#### The cooling fan

The induction hob incorporates a cooling fan. This cooling fan is active when the ovens are on. Under certain conditions, the cooling fan may remain active when the ovens are switched off. This is normal and the fan will switch off automatically.

#### A crack has appeared in the hob surface

Disconnect the cooker immediately from the power supply and arrange for its repair. Do not use the cooker until after the repair.

#### My hob is scratched

Always use the cleaning methods recommended in this guide, and make sure that the pan bottoms are smooth and clean.

Marks from mineral deposits from water or food can be removed with a cleaning cream. However, tiny scratches are not removable but will become less visible in time as a result of cleaning.

#### The oven fan is noisy

The sound of the oven fan may change as the oven heats up - this is perfectly normal.

#### The knobs get hot when I use the oven. Can I avoid this?

Yes, this is caused by heat rising from the oven, heating them up. Do not leave the oven door open.

#### If there is an installation problem and I don't get my original installer to come back to fix it, who pays?

You do. Service organisations will charge for their callouts if they are correcting work carried out by your original installer. Therefore, it's in your own interest to keep track of this installer so that you can contact them as required.

#### Food is cooking too slowly, too quickly, or burning

Cooking times may differ from your previous oven.

Check that you are using the recommended temperatures and shelf positions – see the oven cooking guide.

You can then adjust the settings according to your own individual tastes.

#### The oven is not cooking evenly

Do not use a baking tray with dimensions larger than those specified in the section on 'General Oven Tips'.

If you are cooking a large item, be prepared to turn it round during cooking.

If two shelves are used, check that space has been left for the heat to circulate. When a baking tray is put into the oven, make sure that it is placed centrally on the shelf.

Check that the door seal is not damaged and that the door catch is adjusted so that the door is held firmly against the seal.

A dish of water when placed on the shelf should be the same depth all over. (For example, if it is deeper at the back, then the back of the cooker should be raised up or the front lowered.) If the cooker is not level, arrange for your supplier to level it for you.

#### Oven temperature getting hotter as the cooker gets older

If turning the temperature down using the oven control knob has not worked, or has only worked for a short time, then you may need a new thermostat. This should be fitted by a service person.

#### The oven light is not working

The bulb has probably burnt out. You can buy a replacement bulb (which is not covered under the guarantee) from a good electrical shop. Ask for a 15W – 230V lamp, FOR OVENS. It must be a special bulb, heat resistant to 300°C (Fig.6-1).

Before removing the existing bulb, turn off the power supply and make sure that the oven is cool. Open the oven door and remove the oven shelves.

Locate the bulb cover and unscrew it by turning it counter-clockwise (it may be very stiff) (Fig.6-2).


Now unscrew the existing bulb counter-clockwise, taking care to protect your fingers with a glove in case the bulb should shatter.


Screw in the new bulb clockwise and then screw the bulb cover back on. Turn on the electricity supply and check that the bulb now lights.


#### The oven door is misaligned


The bottom hinge of the left-hand oven door can be adjusted to alter the angle of the door (**Fig.6-3**). Loosen the bottom hinge fixing screws and use the notch and a flat bladed screwdriver to move the position of the hinge to set the hinge position (**Fig.6-4**).

Retighten the hinge screws.









## 7. Installation

#### **Dear Installer**

Before you start your installation, please complete the details below, so that, if your customer has a problem relating to your installation, they will be able to contact you easily.

Installer's Name	
Installer's Company	
Installer's Telephone Number	
Appliance Serial Number	
Appliance Serial Number	

## **Safety Requirements and Regulations**

You must be aware of the following safety requirements & regulations.



This cooker must be installed in accordance with the relevant instructions in this booklet, with the relevant national and local regulations, and with the local electricity supply companies' requirements.



The appliance must be installed in accordance with the regulations in force and only in a well-ventilated space.



Read the instructions before installing or using this appliance.



This appliance is designed for domestic cooking only. Use for any other purpose could invalidate any warranty or liability claim.

## **Provision of Ventilation**

This appliance is not connected to a combustion products evacuation device. Therefore, particular attention must be given to the relevant requirements regarding ventilation.

All rooms require a window that can be opened, or equivalent, while some rooms require a permanent vent in addition to the window.

#### **Location of Cooker**

The cooker may be installed in a kitchen/kitchen diner but NOT in a room containing a bath or shower.


# You will need the following equipment to complete the cooker installation satisfactorily:

- Multimeter (for electrical checks).
- Allen keys (provided in pack).

#### You will also need the following tools:

- 1. Steel tape measure
- 2. Cross-head screwdriver
- 3. Flat head screwdriver
- 4. Spirit level
- 5. 13 mm spanner or socket wrench

#### **Checking the Parts:**



#### INSTALLATION

#### Check the appliance is electrically safe when you have finished.

## **Positioning the Cooker**

Fig.7-1 and Fig.7-2 show the minimum recommended distance from the cooker to nearby surfaces.

The cooker should not be placed on a base.

Above hotplate surround should be level with, or above, any adjacent work surface.

A gap of 75 mm should be left between each side of the cooker **ABOVE** the hotplate level and any adjacent vertical surface.

For non-combustible surfaces (such as unpainted metal or ceramic tiles), this can be reduced to 25 mm.

A minimum space of 800 mm is required between the top of the hotplate and a horizontal combustible surface.

\*Any cookerhood should be installed in accordance with the hood manufacturer's instructions.

\*\*Any splashback must be fitted in accordance with the manufacturers instructions. Allowance should be made for the flue trim, which is fitted to the cooker hob.

Surfaces of furniture and walls at the sides and rear of the appliance should be heat, splash and steam resistant. Certain types of vinyl or laminate kitchen furniture are particularly prone to heat damage and discolouration.

We cannot accept responsibility for damage caused by normal use of the cooker to any material that de-laminates or discolours at temperatures less than 65 °C above room temperature.

We recommend a gap of 1115 mm between units to allow for moving the cooker. Do not box the cooker in – it must be possible to move the cooker in and out for cleaning and servicina.

If the cooker is near a corner of the kitchen, a clearance of 130 mm is required to allow the oven doors to open (Fig.7-3). The actual opening of the doors is slightly less but this allows for some protection of your hand as you open the door.

## **Moving the Cooker**



On no account try and move the cooker while it is plugged into the electricity supply.





⚠ The cooker is very heavy, so take great care.


We recommend that two people manoeuvre the cooker. Make sure that the floor covering is firmly fixed, or removed, to prevent it being disturbed when moving the cooker around.

To help you, there are two levelling rollers at the back, and two screw-down levelling feet at the front.

Remove the polystyrene base pack. From the front, tilt the cooker forward and remove the front half of the polystyrene base (Fig.7-4). Repeat from the back and remove the rear half of the polystyrene base.










#### **INSTALLATION**

#### Check the appliance is electrically safe when you have finished.







#### **Removing the Storage Drawer**

Pull the drawer out to its furthest point.

Push the ends of the plastic clips – down on the left-hand side, up on the right-hand side – to release the catches holding the drawer to the side runners. At the same time pull the drawer forward and away from the side runners (Fig.7-5).

For safety's sake push the drawer runners back out of the way and put the drawer somewhere safe until the installation is complete.

#### **Lowering the Two Rear Rollers**

To adjust the height of the rear of the cooker, first fit a 13 mm spanner or socket wrench onto the hexagonal adjusting nut (Fig.7-6). Rotate the nut – clockwise to raise – counterclockwise to lower.

Make 10 complete (360°) turns clockwise.

Make sure you lower BOTH REAR ROLLERS.

#### **Completing the Move**

Unfold the rear edge of the pack base tray. Open the oven doors so that you can get a good grip on the bottom of the fascia panel as you move the cooker (Fig.7-7).

Carefully push the cooker backwards off the pack base. Remove the pack base tray.

Position the cooker close to its final position, leaving just enough space to get behind it.



DO NOT use the door handles or control knobs to manoeuvre the cooker.

# Repositioning the Cooker Following Connection

If you need to move the cooker once it has been connected then you need to unplug it and, having gripped under the fascia panel and lifted the front of the cooker slightly (Fig.7-7), you need to check behind the cooker to make sure that the electricity cable is not caught.

As you progress, make sure that the electricity cable always has sufficient slack to allow the cooker to move.

When you replace the cooker, again check behind to make sure that the electricity cable is not caught or trapped.

## Levelling

You are recommended to use a spirit level on a shelf in one of the ovens to check for level.

Place the cooker in its intended position taking care not to twist it within the gap between the kitchen units as damage may occur to the cooker or the units.

The front feet and rear rollers can be adjusted to level the cooker. To adjust the height of the rear of the cooker, use a 13 mm spanner or socket wrench to turn the adjusting nuts at the front bottom corners of the cooker.

To set the front turn the feet bases to raise or lower.

#### **INSTALLATION**

Check the appliance is electrically safe when you have finished.

#### **Electrical Connection**

The cooker must be installed by a qualified electrician, in accordance with all relevant British Standards/Codes of Practice (in particular BS 7671), or with the relevant national and local regulations.

#### **Current Operated Earth Leakage Breakers**

The combined use of your cooker and other domestic appliances may cause nuisance tripping, so we recommend that the cooker is protected on an individual RCD (Residual Current Device) or RCBO (Residual Current Breaker with Overload).

# IF IN DOUBT, PLEASE CONSULT A SUITABLY QUALIFIED ELECTRICIAN.

**Note:** The cooker must be connected to the correct electrical supply as stated on the voltage label on the cooker, through a suitable cooker control unit incorporating a double pole switch, having a contact separation of at least 3 mm in all poles.

## A

# The cooker MUST NOT be connected to an ordinary domestic power point.

Access to the mains terminal is gained by removing the electrical terminal cover box on the back panel. Connect the mains cable to the correct terminals for your electrical supply type (**Fig.7-8** and **Fig.7-9**). Check that the links are correctly fitted and that the terminal screws are tight.

Secure the mains cable using the cable clamp.


#### **Final Checks**


#### **Hotplate Check**

Check each cooking zone in turn. Be sure to use pans of the correct size and material.


## **Oven Check**


Turn on the ovens – check that the oven fans start to turn and that the ovens start to heat up.





# INSTALLATION Check the appliance is electrically safe when you have finished.





## **Final Fitting**

## **Fitting the Plinth**

Remove the 3 screws along the bottom edge of the cooker. Hold the plinth in place and refit the 3 screws.

#### **To Fit the Storage Drawer**

Slide the inner side rails out until fully extended (Fig.7-10).

Lift the drawer at its sides and locate one of the drawer rails (approximately 15 mm) onto an inner side rail (Fig.7-11).

Rotate the drawer to locate the remaining drawer rail onto the opposite inner side rail.

Carefully slide the drawer back into the cavity. Some resistance will be felt as the drawer rails locate fully onto the inner side rails.


#### **Customer Care**

**Installer:** Please complete your details in this guide, inform the user how to operate the cooker and hand over the instructions.


Thank you.

# 8. Circuit Diagrams

# **Induction Hob Circuit Diagram**



# **Oven Circuit Diagram**



## Legend

The connections shown in the circuit diagram are for single-phase. The ratings are for 230 V 50 Hz.

Code	Description	
A1	Left-hand oven light switch	
A2	Left-hand oven light	
A3	Right-hand oven light switch	
A4	A4 Right-hand oven light	
B2	Left-hand oven thermostat	
В3	Left-hand multi-function oven switch	
В4	Left-hand oven top element	
B5	Left-hand oven browning element	
В6	<b>B6</b> Left-hand fan element	
B7	Left-hand oven base element	

Code	Description	
В8	Left-hand oven fan	
С	Cooling fan	
D1	Right-hand oven front switch	
D2	Right-hand oven thermostat	
D3	Right-hand oven fan element	
D4	Right-hand oven fan	
E	Thermal cut-out	
F	Neons	
D4 E	Right-hand oven fan Thermal cut-out	

Code	Colour	
ь	Blue	
br	Brown	
bk	Black	
or	Orange	
r	Red	
v	Violet	
w	White	
у	Yellow	
g/y	Green / Yellow	
gr	Grey	

# 9. Technical Data

**INSTALLER:** Please leave these instructions with the user.

**DATA BADGE LOCATION:** Cooker back, serial number repeater badge below door opening.

**COUNTRIES OF DESTINATION:** GB, IE, FR, NL, BE, DE, AT, CH.

#### **Connections**


Electric	230/400V 50Hz
----------	---------------

## **Dimensions**

Total height	Min 915 mm	Max 942 mm	
Total width	1100 mm		
Total depth	600 mm (to fascia); 660 mm (over handles)		
Minimum height above cooker	800 mm		

Refer to 'Positioning the Cooker'.

## **Ratings**



Outro	Left-hand Oven	Right-hand Oven	
Ovens	Multi-function	Forced Air Convection	
Maximum power output @ 230 v 50 Hz	2.5 kW	2.5 kW	
Energy efficiency class on a scale of A (more efficient) to G (less efficient)	Α	A	
Energy consumption based on standard load	0.95 kWh	0.90 kWh	
Usable volume (litres)	78	78	
Size	Large	Large	
Time to cook standard load	41 minutes	38 minutes	
Surface area of the grid	1400 cm <sup>2</sup>	1400 cm <sup>2</sup>	

Maximum total electric load at 230 V 50 Hz (approximate total including oven lights, oven fan, etc.): 16.2 kW.

26			

Name of Appliance & Colour*				
Appliance Serial Num	ıber*			
Fuel Type*	Natural Gas		LP Gas	
Тисттурс	Dual Fuel		Electric	
Retailer's Name & Ad	dress			
Date of Purchase				
Installer's Name & Address				
Installer's Telephone Number				
Date of Installation				

 This information is on the appliance data badge – look in the appliance instructions to find out where the data badge is located.

#### **CONSUMER SERVICE**

If you have any product enquiries, or in the event of a problem with your appliance once it has been installed, please telephone 0870 789 5107.

#### **CONSUMER SERVICE LINES OPEN:**

Monday to Thursday 8am-6pm Friday 8am-5pm Saturday 9am-1pm

#### **WARRANTY**

Your manufacturer warranty covers goods of our own brand for defective workmanship and materials for a period of 3 year from the date of purchase. This warranty covers mechanical breakdown and proven cosmetic and manufacturing defects.

To register for this guarantee simply fill in and return the FREEPOST registration form provided. Alternatively call free on 0800 694 4170, quoting reference FAGX91AN or register online at www.falconappliances.co.uk

Any damage, blemishes or chips identified upon receipt of the product must be reported within 90 days ñ proof of purchase may be required to establish validity. Scratches on the surface of ceramic hobs must be reported within 14 days. Scratches caused by usage are not covered. Accidental damage is not covered by the manufacturer's warranty.

# For warranty compliance, the requirements are that the appliance:

- Has been correctly installed in accordance with current legislation, relevant British and European Standards and Codes of Practice, by a suitably competent person registered with Gas Safe or equivalent body and, where applicable, a qualified electrician.
- Has been used solely for domestic cooking purposes.
- Is in use in the UK\*, has not been taken abroad as a personal export. (In the Republic of Ireland conditions may vary, so consult your retailer.)
- Is not second-hand or a refurbished appliance. The manufacturer's warranty is not transferable.
- Has not been subject to misuse, accidental damage or modification, and has not deteriorated due to normal domestic wear and tear, and the manufacturer's recommendations concerning cleaning materials have been followed.
- Has not been repaired by persons or organisations other than those authorised to act on behalf of AGA Rangemaster.

#### **Exceptions:**

- Items not included under the free 3 year guarantee include pan supports, griddles, wok rings, baking trays, grill pans, trivets, filters, light bulbs and other consumable accessories.
- Any damage caused other than through normal use.
- Breakdowns associated with cooking spillage.
- Cosmetic deterioration deemed to be normal wear and tear.

#### This warranty is in addition to your Statutory Rights.

\* Only certain models can be adapted for use with Mains Gas supplied in the Channel Islands and Isle of Man.

••••••

#### **OUT OF WARRANTY**

We recommend that Falcon appliances are serviced regularly throughout their life to maintain optimum performance and efficiency. Service work should only be carried out by technically competent and suitably qualified personnel.

For your own safety, always make sure that work is carried out by a Gas Safe registered engineer for gas appliances or an approved electrician for electrical models.

For a competitive quote and to arrange for a Falcon approved engineer to attend, call Consumer Services on: 0870 789 5107.

#### **SPARE PARTS**

To maintain optimum and safe performance, we recommend that only genuine Falcon spare parts are used. These are available from most major spares stockists, including ourselves.

Contact Consumer Services on 0870 789 5107, who will be happy to help.

#### **STANDARDS**

Falcon cookers are designed and manufactured to a recognised international quality standard, which meets the requirements of BS EN ISO 9001, BS EN ISO 14001 and OHSAS 18001 for continually improving environmental procedures.

.....

Falcon cookers comply with the essential requirements of the appropriate European Directives, and carry the CE mark.



For over 45 years
DIVERTIMENTI, Falcon's
sister company, has
been the ultimate destination
for food lovers and serious
chefs alike. With its vast array
of cookware, tableware and
kitchenware, DIVERTIMENTI
caters to all your culinary needs.
With over 4500 items on the
DIVERTIMENTI
website www.divertimenti.co.uk



Falcon Appliances
Clarence Street
Royal Leamington Spa
Warwickshire
CV31 2AD
Tel 0870 755 6490
Fax 0192 631 1032

Email consumers@falconappliances.co.uk www.falconappliances.co.uk Trade Enquiries 0115 946 6143 Email sales@falconappliances.co.uk

Registered in England and Wales. Registration No. 354715 Registered Office: Juno Drive, Leamington Spa, Warwickshire, CV31 3RG

Falcon continuously seeks improvements in specification, design and production of products and thus, alterations take place periodically. Whilst every effort is made to produce up-to-date literature, this booklet should not be regarded as an infallible guide to current specification, nor does it constitute an offer for the sale of any particular appliance.





